

CorkSport

MAZDA PERFORMANCE



2003-2008 Mazda 6 and 2006-2007 MazdaSpeed 6 Rear Floor Bar Install Instructions

Tool required

- 14mm Wrench (Most vehicles)
- Torque Wrench with 14mm socket
- 3/8 Drive Ratchet

Contents

- 2 M10 x 1.50 thread x 45mm Long Flange Bolts (Regular 6)
- 2 M10 x 1.25 thread x 45mm Long Flange Bolts (MS6)
- 1 CorkSport Rear Floor bar
- 6 Page Installation Instructions

NOTE: These instructions are provided for reference only. It is recommended that you have a FSM as well. Installation of this bar should take about an hour. Instructions for the MazdaSpeed 6 are after the Regular 6 instructions.

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

2003-2008 Mazda 6 (see page 4 for MS6)

Step 1: Open trunk, and lay rear seats flat. Lift trunk carpet up and back towards the rear of your 6.



Step 2: Remove 14mm head bolt from rear seat brackets, one (1) on each side.



Step 3: Place CorkSport rear bar in vehicle as shown. Using the two (2) supplied M10 x 1.50 thread bolts, install bolts through bar and seat brackets and tighten bolts to 34-46ft/lbs.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

Step 4: Place trunk carpet back to original position, close seats, doors and trunk. You are finished.

NOTE: The floor carpet covers the bar. If you would like bar to show, trimming of the carpet will be required.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

2006-2007 MazdaSpeed 6

Step 1: Open trunk of your MS6.

Step 2: Remove five (5) plastic clips from panel behind rear seats. Remove panel from 6.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

Step 3: Locate seat lock release levers on bottom of deck panel and push lever to unlock seats and fold them forward.



Step 4: From inside passenger doors, remove two (2) 14mm head bolts from each side of the 6 seat brackets.



Step 5: Install CorkSport floor bar over seat brackets and install the two (2) supplied M10 x 1.25 thread bolts. Tighten bolts to 34-46ft/lbs.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

Step 6: Return seat backs to there locked position. From inside the trunk area, replace panel with its original 5 plastic clips.



Installation complete. Next pictures are of a bar installed prior to the seat backs and trunk panel being returned to normal in the 6.



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK