

Step 7 — Mount Wing Extension in Final Locations



- Push the wing on the sides so it contours the OEM surface. This is flat against the surface
- Using the holes in the Wing Extension as a guide, drill the **Qty(4)** bolt holes with an **1/8" Drill bit**. The 90deg tool may be needed
- Release pressure from holding the wing and clean the surface
- **i** The wing will hang from the top brackets. This is normal
- Once drilled, use the remaining **Qty(4)** #10 Self-tapping screws to attach the wing to the vehicle
- **⚠ Tighten until snug. Do NOT overtighten**
- With the **Socket** on the **Wrench** and the **Wrench** on the other, tighten the top Qty(3) 10mm bolts completely
- Give the wing a slight wiggle to test its sturdiness. If there is any flex or rattle, tighten the bolt closest to where the flex is occurring

Step 8 — Installation Complete



- This completes the installation of your new CorkSport Performance Wing Extension!
- Contact us with any questions or concerns at sales@corksport.com or (360) 260-2675. Leave us a review at: <https://corksport.com>
- Share your experience using #CorkSport on Instagram, Facebook, and Twitter.