

# CorkSport

MAZDA PERFORMANCE



## Installation Instructions for CorkSport Mazdaspeed 6 Front Shock Tower Bar

### Tool required

- 14mm wrench
- Torque Wrench with 14mm socket

Step 1: Park your car on a flat level surface and set the e-brake.

Step 2: With the 14mm wrench remove the six (6) nuts, three (3) per side from the top of the strut tower.

Step 3: Place the CorkSport strut bar onto the studs that protrude through the strut towers.

Step 4: Tighten down the six (6) nuts to 33-46 ft lbs and you are ready to go!



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK