



CorkSport Urethane Exhaust Hangers

Tools needed:

- Jack or lift
- Jack Stands
- WD-40 or other Lubricant
- Long Flat Head Screw Driver or Pry Bar

Step 1: Jack up the vehicle and use jack stands to support your car or use a lift.

DANGER: Follow instructions that came with your jack/stands. Death and or significant property damage could result if you do not.

Step 2: Spray WD-40 or other lubricant on the hangers for ease of removal.

Step 3: Change one hanger at a time remove and reinstall the CS hanger. Use a little spray of WD-40 if the hanger is still difficult to slide on. Make sure the hangers are on securely.

Step 4: Put the vehicle back on the ground.

Thank you for your purchase. If you have any questions please call CorkSport at 360 260 CORK