

[ c o r k s p o r t ]



Installation Instructions for the CorkSport Type "MS" Lip for 89-91 RX-7

Tools required

- |  |   |
|--|---|
| <ul style="list-style-type: none"><li>• Sand Paper 80 grit</li><li>• Philips Screw Driver</li><li>• Floor Jack</li></ul> | <ul style="list-style-type: none"><li>• Two Jack Stands</li><li>• 1/4 or 3/8" drive Ratchet</li><li>• 8mm Wrench and Socket</li></ul> |
|--|---|

Parts Included

- |  |
|--|
| <ul style="list-style-type: none"><li>• Type 'MS' Lip</li><li>• 4 Page Installation Instructions</li></ul> |
|--|

CorkSport recommends this lip be installed by a professional auto body shop that has experience in aftermarket components. If you wish to install the lip yourself we have included this set of instructions to help the Do-It-Yourselfer install the CorkSport Type 'MS' lip. Proceed at your own risk.

**CAUTION:** Installation of the lip will make the front of your car lower and sit further forward. Take care when entering driveways or pulling up to curbs so as not to hit your lip and damage it.

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

**TIP:** CorkSport recommends that you test fit the lip before installation and painting to make sure the contours of the lip fit the bumper evenly. We recommend putting blue painters tape against the bumper when doing the initial test fit to keep from scratching the paint on your bumper.

**DANGER:** Follow instructions that came with your jack/stands. Death and or significant property damage could result if you do not.

Step 1: Jack up front of RX-7 and place securely on jack stands.

Step 2: Remove 2 Philips head screws (1 on each side) from factory lip to fender.



Step 3: Remove 15 8mm/Philips head screws from factory lip to bottom of bumper. Remove lip.



Pictures continued on next page.

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK



Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK

Step 4: Using 9 of the original 8mm head screws, install CorkSport type "MS" lip on bottom of bumper and tighten screws.



This concludes the installation instructions for your new CorkSport type "MS" lip.

Thank you for your purchase. If you have any questions please call Cork Sport at 360 260 CORK