

Part # AXL-9-541

**CorkSport**  
MAZDA PERFORMANCE

# CorkSport Carpet Floor Mats

2010-2013 Mazdaspeed 3

①



②



③



④



## **This Package should contain:**

- ❑ 1. One Front Driver Side Floor Mat
- ❑ 2. One Front Passenger Side Floor Mat
- ❑ 3. One Rear Drivers' Side Floor Mats
- ❑ 4. One Rear Passengers' Side Floor Mat

# CorkSport Carpet Floor Mats

2010-2013 Mazdaspeed 3



**Freshen up your ride with the new CorkSport Carpet Floor Mats designed for the 2010-2013 Mazdaspeed 3.**

With OEM fitment and show car quality, these floor mats are sure to add that extra level of detail to your Speed.

The CorkSport Carpet Floor Mats include both the front and rear for a complete package.

Give your feedback for the CorkSport Carpet Floor Mats by submitting a review at:

<http://corksport.com/mazdaspeed-3-mazda-3-floor-mat-set.html>

## Pre-Installation Notes:



**These instructions were written for reference only** and the use of a factory service manual is recommended...if this is even in the OEM service manual.



**Shedding Period:** The new floor mat carpet will have a small amount of loose fibers that will come out in the first week of use. This is normal. Pre-vacuuming the floor mat will speed up the shedding process



**These in car installation photos were produced using a 2013 Mazdaspeed 3.** 2010-2013 Mazdaspeed 3 will be similar.



**High Theft Item:** Your friends will be extremely jealous, therefore they will try to steal your new floor mats!

## Materials and Time:



### General Info.

Part #: AXL-9-541-10

Time Est: 15 Minutes

Wrench Rating: 1/5



### Tooling List

Vacuum



### Parts List

1. One Front Driver Side Floor Mat
2. One Front Passenger Side Floor Mat
3. Two Rear Floor Mats

Need Help With Your Installation?

Call (360) 260-CORK

Part # AXL-9-541

**CorkSport**  
MAZDA PERFORMANCE

## Detailed Instructions

### 1. CorkSport Floor Mat Installation

- a) **Disconnect the negative battery terminal** with a 10mm wrench...Just Kidding you don't need to do that.
- b) **(Optional) Vacuum the CorkSport Floor Mats lightly to remove excess fibers.** (This will speed up the "shedding process")
- c) **Remove what ever excuse for floor mats you currently have** and throw them in the garbage.
- d) **Install the CorkSport floor mats** in their appropriate location utilizing the eyelets and hooks for the front mats. Refer to cover page for locations.
- e) **This completes your installation!** Now go show them off!



Passenger's Side



Driver's Side

Need Help With Your Installation?  
Call (360) 260-CORK